

SPARE PARTS CATALOGUE
CULTIVATORS/TILLERS: HUSQVARNA TR 262

Spare Parts List

Frequent Parts


Accessories

SPARE PARTS LIST

CULTIVATORS/TILLERS

HUSQVARNA TR 262


E TR 262
TRANSMISSION



CULTIVATORS/TILLERS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	599348641	COVER KIT	End cover kit	1
2	599348642	GEAR ASSY		1
3	599348640	DRIVE SHAFT		1
4	599348639	BEVEL GEAR ASSY		1
5	599348643	COVER ASSY	Gearbox cover assy	1
6	599348654	GASKET		1
7	599348616	BEARING	Bearing 6202	1
8	599348653	DRIVE SPROCKET		1
9	599348652	CHAIN	Chain 520HF3-1*18L	1
10	590831601	BEARING		1
11	593601436	GASKET		1
13	599348645	BEARING	Bearing 6203-2rs	1
14	593601407	BEARING		1
15	599348646	GEARBOX	Tilling gearbox	1
16	599348644	SCREW KIT		1
17	599348651	DRIVE SPROCKET		1
18	599348650	CHAIN	Chain 520HF3-1*38L	1
19	599348649	SPROCKET		1
20	599348648	SHAFT	Output shaft	1
21	599348647	KEY	Key 8*7*32	1
22	536060501	COUPLER		1


B TR 262
TRANSMISSION BACK CASE COMP



CULTIVATORS/TILLERS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	599348624	GEAR ASSY		1
2	599348623	GEAR ASSY		1
3	599348627	SHAFT	REVERSE SHAFT	1
4	599348625	FORK	SHIFTING FORK KIT	1
5	599348628	FORK	REVERSE FORK	1
6	599348626	GASKET KIT		1
7	599348622	GEARSHIFT LEVER		1
8	599348665	LEVER ASSY	Shifting lever assy	1
9	599348620	SCREW KIT		1
10	599348621	BEARING KIT		1
11	599348619	BEARING	Bearing 6004	1
12	599348631	GASKET		1
13	599348630	COVER	End cover	1
14	599348629	OIL PLUG		1


A TR 262
TRANSMISSION CASE



CULTIVATORS/TILLERS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	599348701	CLUTCH ASSY		1
2	599348702	PLUG KIT		1
3	599348703	CLUTCH LEVER		1
4	599348638	GASKET		1
5	599348614	GASKET		1
6	599348615	BEARING	Bearing 6007	1
7	599348616	BEARING	Bearing 6202	1
8	599348617	GEARBOX		1
9	599348618	DIPSTICK		1
10	599348619	BEARING	Bearing 6004	1


D TR 262
WALKING CASE COMP



CULTIVATORS/TILLERS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	599348632	GEARBOX ASSY		1
2	599348633	SEAL KIT		1
3	599348634	BEARING KIT		1
4	599348638	GASKET		1
5	599348635	BEARING	Bearing 6305	1
6	599348636	BEARING	Bearing 30206	1
7	599348637	GASKET		1


J TR 262
WHEEL



CULTIVATORS/TILLERS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	599348699	WHEEL KIT		1
2	599348698	WHEEL AXLE	kit	1
3	599944701	RIM		1
4	599348696	WHEEL AXLE		1
5	599348697	TIRE		1


I TR 262
COVERS



CULTIVATORS/TILLERS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	599348693	COVER ASSY	Sider cover R.	1
2	599348688	BRACKET		1
3	599348685	WHEEL KIT		1
4	599348692	SCREW KIT		1
5	599348690	COVER ASSY		1
6	599348689	PLATE		1
7	599348694	COVER ASSY	Tine cover assy	1
8	599348691	COVER ASSY	Sider cover L.	1
9	599348687	BAR	Drag bar	1
10	599348686	SUPPORT WHEEL		1
11	599348695	COVER	Rear tine cover	1


F TR 262
ENGINE AND CONNECTIONS



CULTIVATORS/TILLERS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	599348659	ENGINE	See Husqvarna Engine IPL Separately	1
2	599348704	BUMPER		1
3	599348658	HOLDER	CABLE HOLDER	1
4	599348655	ENGINE PLATE		1


G TR 262
HANDLE



CULTIVATORS/TILLERS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	599348663	COVER ASSY	Upper cover assy	1
2	599348656	COVER	TIDY COVER	1
3	599348661	COVER ASSY	Handlebar cover assy	1
4	599348664	CABLE ASSY	Adjusting cable assy	1
5	599348662	CABLE ASSY	Height adjusting cable assy	1
6	599348668	HANDLEBAR BRACKET	Turning seat assy	1
7	599348657	HANDLE SUPPORT ASSY	Handlebar seat assy	1
8	599348658	HOLDER	CABLE HOLDER	1
9	599348666	LEVER ASSY		1
10	599348667	BEARING KIT		1
11	599348660	CABLE HOLDER		1
12	599348677	HANDLEBAR		1
13	599348676	THROTTLE CABLE		1
14	599348675	THROTTLE CONTROL		1
15	599348673	CLUTCH LEVER		1
16	599348674	CABLE	Adjusting cable	1
17	599348672	STOP SWITCH		1
18	599348669	GRIP		2
19	599348670	CLUTCH LEVER		1
20	599348671	CABLE	Clutch cable	1


C TR 262
HARDWARE



CULTIVATORS/TILLERS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	529338101	SERVICE KIT	Hardware Kit	1

H TR 262
TILLER TINE



CULTIVATORS/TILLERS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	599348678	BLADE	Blade R.	6
2	599348679	BLADE	Blade L.	8
3	599348682	PIN	Pin ?8	2
4	599348681	HOLDER	Outer holder L.	1
5	599348680	HOLDER	Inner holder L.	1
6	599348684	HOLDER	Inner holder R.	1
7	599348683	HOLDER	Outer holder R.	1
8	587958801	NUT		1
9	590642101	BOLT		1
10	598684202	BOLT		1
11	590615501	WASHER		1

