

SPARE PARTS CATALOGUE


**LAWN MOWERS: CONSUMER WALK-BEHINDS: HUSQVARNA LC
153P**

Spare Parts List

SPARE PARTS LIST

LAWN MOWERS: CONSUMER WALK-
BEHINDS


HUSQVARNA LC 153P



LAWN MOWERS: CONSUMER WALK-BEHINDS


PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	598684111	PLATE KIT	SIDE DISCHARGE PLATE	1
2	598684119	FLAP	REAR DOOR	1
3	598684128	SEALING PLATE	SEALING PLATE	1
4	598861201	CHASSIS	chassis	1
5	598684122	COVER KIT	FRONT COVER	1
6	598818701	AXLE	WHEEL AXLE	1
7	598512901	WHEEL	FRONT WHEEL	2
8	598721701	DUST SEAL	DUST-PROOF RING	1
9	598513301	AXLE	REAR SHAFT	1
10	598684109	AXLE	WHEEL AXLE	1
11	598684103	WHEEL	FRONT WHEEL	2
12	599138801	ROD	connecting rod	1
13	599138901	SPRING	tension spring of connecting rod	1
14	598819001	COVER	SIDE DISCHARGE PROTECTIVE COVER	1
15	599139101	HANDLE KIT	HEIGHT ADJUSTMENT HANDLE	1
16	599139001	PLATE KIT	HEIGHT ADJUSTMENT PLATE	1

D LC153P
GRASS HANDLING



LAWN MOWERS: CONSUMER WALK-BEHINDS


PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	598684121	GRASS BAG ASSY	GRASS BAG KIT	1



LAWN MOWERS: CONSUMER WALK-BEHINDS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
2	598684107	HEIGHT ADJUSTER	HEIGHT ADJUSTER	1
3	598742601	INSTALLATION KIT	BOLTS AND NUTS	1
4	598513501	COVER	BELT COVER	1
5	598684105	BLADE SUPPORT	BLADE ADAPTER	1
6	598562601	BLADE	Collect blade	1
7	598018001	MULCH KIT	MULCHING KIT	1
8	597683901	BLADE	Mulch blade	1

B LC153P
HANDLE



LAWN MOWERS: CONSUMER WALK-BEHINDS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	598818201	BAIL ARM ASSY	BAIL ARM	1
2	598722001	HANDLE KIT	HANDLE AND SHEATH	1
3	598684129	BAIL ARM ASSY	BAIL ARM	1
4	598825601	HANDLE KIT	HANDLE	1
5	598861501	CABLE ASSY	choke cable assy	1
6	598861401	CLIP	cable clamp	1
7	598684125	KNOB ASSY	KNOB	1
8	598684113	SUPPORT KIT	HANDLE BRACKET	1